**RO-WERKS** INSTRUCTION SHEET

1931 N 24th Ave., Mears, MI 49436 · Phone: 231-873-4252 · Fax: 231-873-0218 · www.pro-werks.com

# SELF-LUBRICATING BEARINGS

C52-090-2, C52-092-2, C52-094-2, C52-096-2, C52-098-2

#### About this product:

These self-lubricating bearings are ideally suited for low to medium load applications, providing high levels of wear resistance during slow rotating, oscillating or axial motion. Designed for use without lubricant although medium to high viscosity fluid lubrication is possible, if desired.

#### Installation:

Part #	Shaft Size	Housing Bore	Clearance
C52-090-2	.624625″	.750751″	.0020057″
C52-092-2	.749 - 750″	1.00 - 1.001″	.00250069"
C52-094-2	.874875″	1.125 - 1.126″	.00250069"
C52-096-2	.999 - 1.00"	1.250 - 1.251"	.00250069"
C52-098-2	1.249 - 1.250"	1.4995 - 1.5005"	.00320110"
* Clearance between shaft and bearing after assembly			

### Safety Concerns:

Any questions regarding use or installation should be directed to Pro-Werks. If necessary, reference applicable sanctioning body for minimum rule requirements.

## **IMPORTANT, PLEASE READ:**

Before using any product read the product warranty printed below. If you do not agree with what it says, promptly return the product and your money will be refunded. Use of this product indicates that you accept the terms of this warranty.

Neither the seller nor the manufacturer will be liable for any loss, damage or injury directly or indirectly arising from the use of or inability to determine the use of these products. Before using, the user(s) should determine the suitability of the products for its intended use, and the user(s) shall assume all responsibility and risk in connection therewith.

D001 8-27-01

8-27-01 Rev. 11-01-18